Setting up an Axis Camera to allow ONVIF Users

Find the Camera to be installed and click on that ID



The video feed will pop up. Go into Setup.

If prompted for a User/Password default is root/pass



Setting up an Axis Camera to allow ONVIF Users

This will bring you to the main setup page. To set up the ONVIF User go to System Options



This will bring up a new list. Under Security select ONVIF



Setting up an Axis Camera to allow ONVIF Users

Under ONVIF add a new user as Administrator



Setting up an Axis Camera to allow ONVIF Users



The Camera is now setup to accept ONVIF users and work with the IP Pro series